
Step 1 – if you don't already have the drivers in your possession, **download** the PERSEUS **USB Drivers** from this location and unzip the file:
https://www.microtelecom.it/en/download?path=microtelecom%2FPerseus%2FSoftware%2FDrivers


Step 2 – **power on and connect** the PERSEUS to your computer using an USB A-B cable.

Step 3 – open the **Windows Device Manager**, select the Unknown Device, right click and choose Update driver.




 © 2026 ELAD S.r.l.

Step 4 – choose to **browse** for your computer.




Step 5 – once chosen the correct folder ("**PerseusDriversUpdate2026a1**"), click Next.




© 2026 ELAD S.r.l.

Step 6 – the **outcome window** must be the one below.



© 2026 ELAD S.r.l.

Step 7 – check the PERSEUS is correctly shown in the **Windows Device Manager**.



Notes:

- find PERSEUS software and drivers here: https://www.microtelecom.it/en/download?path=microtelecom%2FPerseus%2FSoftware
- find PERSEUS user manuals here: https://www.microtelecom.it/en/download?path=microtelecom%2FPerseus%2FUser_manuals

© 2026 ELAD S.r.l.